INSTALLATION INSTRUCTIONS FOR 1472-562

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER .
AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

ASSEMBLING THE FIXTURE (Fig.2)

1. Shut off the power at the fuse box or circuit breaker. If necessary, remove the old fixture, including the mounting hardware.
2. Carefully unpack the new fixture and lay all the parts on a clear area. Take care not to lose any parts necessary for installation.
3. Attach the column (K) to the column (M) by turning it clock wise until tight.
4. Attach the column (M) to the fixture body (U) by turning it clock wise until tight.
5. Place the arm (T) onto the fixture body (U) aligning the hole, attach the collar ring (R) and the washer (S) and lock it securely with the screw (Q).

HANGING THE FIXTURE (Fig.1)

6. Thread the nipple (C) into the loop (F) until snug.
7. Thread the other end of the nipple (C) with the loop attached into the crossbar (D) until snug.
8. Place the lock washer (B) over end of the nipple (C) protruding through the crossbar and thread the hex nut (A) onto the nipple until tight.
9. Take the crossbar assembly and mount to ceiling junction box with the junction box screws (E) (Size: #8-32*1"L). Tighten the screws securely with a screwdriver.
10. Use proper chain pliers to open one end link of the chain and connect it to the fixture loop (J). Close the link.
11. By measuring, determine correct number of links needed for proper hanging height. Using proper chain pliers to disconnect and discard remaining chain.
12. Lace the fixture wires through the chain.
13. Slip loop collar (H) and the canopy (G) and the canopy (I) over the chain.
14. Open the other end link of the chain and hang the fixture on the loop at the ceiling. Close the link.
15. Feed the fixture wires through the loop (F) and nipple (C) and pull until tight.

CONNECTING THE WIRES (Fig.3)

16. Connect the electrical wire as shown in figure 3, making sure that all wire connectors are secured. If your outlet has a ground wire (green or bare copper), connect the fixtures ground wire to it. If the junction box has no ground wire, attach the bare copper fixture wire to the green ground screw (Screw: #8-32*3/8"L) on the crossbar. Tuck the wire connections neatly into the ceiling junction box.

COMPLETING THE INSTALLATION (Fig.2)

17. Raise the canopy (I) and the canopy (G) all the way to the ceiling; then raise the loop collar (H) and thread into ceiling loop protruding through canopy.
18. Place the two glass plates (P) (smooth side will be on the top) over the fixture body (U) aligning the pipe nipple, attach the collar ring (O) and lock it securely with the nut (N).
19. Thread the pipe (W) into the nipple bottom of lamp body (U), then lock it tightly with the hex nut (V).
20. Install the light bulbs (not included) in accordance with the fixture's specifications: **DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)**
21. Attach the glass shade (X) to the fixture body (U) aligning the hole with the pipe nipple and lock it securely with the brass nut (Y), then attach the finial (Z).
22. Hang the adorning (L) to the loop on the column (K) and the arm (T).

Your installation is now complete. Return power to the junction box and test the fixture.

Fig.1



Fig.2



CHAIN HUNG FIXTURE INSTRUCTION

Notice: It is important to use proper chain pliers (not included) To OPEN and CLOSE the chain included with this fixture. Do not open them with other tools that may twist or stress the chain links. It is important to use proper chain pliers like the ones shown in the diagram.



Fig.3


FIXTURE WIRES Black or Smooth
HOUSE WIRES Black (Hot)
FIXTURE WIRES White or Ribbed
HOUSE WIRES White (Neutral)
FIXTURE WIRES Bare Copper (Ground)
HOUSE WIRES Green or Bare Copper (Ground)

c ETL us Intertek

american lighting association